Closed circuit cooling towers

Options and accessories

Electrical panel heater



The default iPilot® electrical panel is equipped to be installed in ambient temperatures that go down to -10°C.
For climates where the ambient temperature can become even lower, an electrical heater can prevent damage to the internal components inside the electrical panel for ambient temperatures as low as -40°C.

Want to install a Nexus® in a climate with ambient temperatures as low as -40°C? Contact your local BAC representative.